

PRESET TORQUE SCREWDRIVER

- Right angle handle, easy operation
- Meet DIN ISO 6789
- Torque value can be preset within the adjust range (torque adjustment tool **IST-P-TOOL** and torque tester are needed)
- Clockwise and counter-clockwise operation



IST-PH1



torque adjust tool (optional)

SPECIFICATION

| Code | IST-PH1 | IST-PH2 | IST-PH3 |
|---------------|--------------------------|--------------------|-----------------|
| Head type | 1/4" square driver | 3/8" square driver | 1/4" hex socket |
| Adjust range* | 2~17N.m | | |
| Accuracy | ±6%(<10N.m), ±4%(≥10N.m) | | |
| Length | 155mm | | |
| Weight | 343g | | |

OPTIONAL ACCESSORY

| | |
|--------------------|------------|
| Torque adjust tool | IST-P-TOOL |
|--------------------|------------|

* Adjust to a fixed torque value according to the need